PERFORMANCE+

Cleaning instructions



crevin

PERFORMANCE+

PERFORMANCE+ is a fabric concept that guarantees clean and untroubled living and working spaces.

Thanks to its easy clean properties, soils and stains can be easily removed from an **PERFORMANCE+** fabric. For a thorough periodical cleaning, **PERFORMANCE+** fabrics can be machine-washed at 30°C.

The protection of **PERFORMANCE+** is safe and frequent cleaning will not damage the fabric.

crevin

PERFORMANCE+

Care & Cleaning

Designed for high-traffic areas with an elevated risk of soiling and staining, PERFORMANCE+ fabrics are very easy to maintain and practically all kinds of common stains can be easily removed. For easy day-to-day maintenance of your PERFORMANCE+ fabrics follow the instructions below.

Stain Removal

- 1. Treat stains as soon as they occur.
- Remove any excess of soiling material using absorbent paper in the case of spills and oily stains, and a knife or spatula in the case of crusted or dried-on stains.
- Wipe the stain with a clean cloth using a solution of lukewarm water mixed with a few drops of neutral detergent or handwash.
- 4. With persistent stains moisten or spray the upholstery fabric directly with soapy water and then rub. Repeat the treatment if necessary.
- When the stain has disappeared rinse with clear water to remove all soap residue, and rub dry with a clean towel.
- Let air-dry at room temperature. Do not use hair dryers.

Note: in case water rings or water stains remain after the cleaning, clean the entire surface area of the sofa cover, from seam to seam.

Machine-washing

- Wash the sofa covers inside out and with the zipper closed.
- 2. When the sofa cover uses Velcro instead of a zipper, attach a protective cloth or strip over the Velcro, this to avoid damage to the fabric.
- 3. Use neutral detergents and do not use softener.
- 4. Wash at the recommend temperature (in case of doubt, wash at 30°C), using a washing program with delicate cycle.
- 5. Use minimum centrifugation (800 rpm).
- 6. Do not wash with other textiles and do not load the washing machine excessively.

Drying

- 1. With the cover still moist stretch in both directions.
- 2. Dry flat at environmental temperature.
- 3. Avoid direct exposure to sunlight.
- 4. Always assure that the cover is completely dry before usage.



















www.crevin.com/performance+

