

A Crevin fabric is a valuable product that is designed to be enjoyed over a long period of time. To keep furniture in optimal conditions, the upholstery should be used and maintained properly. In order to assure the best cleaning results, carefully follow the care instructions in this guide.

Machine-washing

1. Wash the sofa covers inside out and with the zipper closed.
2. When the sofa cover uses Velcro instead of a zipper, attach a protective cloth or strip over the Velcro to avoid damage to the fabric.
3. Use neutral detergents and do not use softener.
4. Wash at the recommend temperature for each fabric (in case of doubt, wash at 30° C), using a washing program with delicate cycle.
5. Use minimum centrifugation (800 rpm).
6. Do not wash with other textiles and do not load the washing machine excessively.

